


PERFUME DISPENSER USER MANUAL

Thank you for purchasing this auto perfume dispenser, which adopts CPU and LCD display technology. It has reliable function, accurate timing and low power. The LCD shows the working status directly which make it more convenient to users. The spraying interval and spraying time can be change according to the size of space, density of population, and air condition. It is an ideal choice for hotel, hospital, restaurant and other public places.




Components:

- 1.Cover
- 2.Mounting hole
- 3.Base
- 4.Tin Clamp
- 5.Key
- 6.MODE
- 7.+ / SET
- 8.CONFIRM
- 9.SPRAY
- 10.POWER
- 11.Batteries
- 12.Batteries cover buckle
- 13.Batteries cover



Installation:

1. Use the key attached to unlock the cover, and follow the direction in (Figure1) to open it.
2. As shown in (Figure3), drill 2 holes of 6mm diameter 30mm deep, and fix the hanger with the plugs and screws. Fit the dispenser right to the hanger, and fix it with the screw. (Figure4)
3. During install the aromatic spray, fit the back of the nozzle from the spray right to the spout location, place the bottleneck to the groove, and press the aromatic spray to the position.
4. Place 2 pieces of 1.5V20R batteries into the base (Figure2)
5. The dispenser should be installed in the height that can not spray to people or things directly.



Application:

- 1.Functions:
 - a.The time of staring and ending spraying every day can be set randomly
 - b.The sparing interval (1minute-4hours) can be set randomly
 - c.The working days (Monday-Sunday) for week can be set randomly
 - d.With switch off the power, pressing the SPRAY button can set if the dispenser sprays or not; when setting not spray, the clock in the display keeps running
- 2.When switch ON the power, the dispenser will spray once and works as default setting. Default setting: 30 minutes spraying interval, daily working (Monday-Sunday), 24-Hour spraying time, and clock starts from 00:00.