

INSTALLATION INSTRUCTIONS AND TEMPLATE

Warm air hand dryer. Intended for use in a household environment by non-expert users. Not suitable for outdoor use.

IMPORTANT

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

If a fault develops disconnect the electrical supply, a qualified electrician should be called.

ELECTRICAL CONNECTION

This appliance is intended for connection to fixed wiring.

A fused means for disconnection in all poles must be provided in the fixed wiring in accordance with the wiring rules. Check that the electrical rating shown on the Hand Dryer (rating label) is compatible with the electrical supply.

WARNING: THIS PRODUCT MUST BE EARTHED.

Installation must be supervised by a qualified electrician.

Installation and wiring must conform to current IEE Regulations (UK), local or appropriate regulation (other countries).

Connect the ground / earth supply to the terminal marked \perp , the Live supply to the terminal marked (L) and the Neutral supply to the terminal marked (N).

MAINTENANCE - Prior to carrying out any maintenance, ensure that the electrical supply has been disconnected.

The cover should be wiped occasionally with a damp cloth to remove surface marks.

Do not use abrasive cleaning agents.

Every six months (more frequently in a dusty environment) the inlet and outlet grilles should be cleaned with a small brush to remove accumulated debris.

