
DAILY USE & MAINTENANCE



Prohibited

- the machine
- Place the unit away from direct water supplies
- A suitably rated fused power supply is required
- Ensure the correct power supply is used, if more than +/-10% the unit may malfunction

electrician

- The power must be turned off during maintenance
- The drain tank and air filter must be installed for excessively wet correct operation


Ensure the unit has a reliable earth connection


Do not install connected to a power supply

Do not allow


unit to get

Do not • This hand dryer must be installed by a qualified dismantle





ELECTRICAL SCHEMATIC



PACKING LIST

Crocodillo T2
30mm self tapping screws5
5mm expansion pipe
User manual1

	Voltage	AC220- 2400V~	Motor	Brush motor
	Phase	Single-phase	Sensing distance	9–15cm
	Input	1400-1650W	Protection class	IPX4
	Air drying speed	105m/s	Unit dimensions	250 x 175 x 488mm
	Heating power	800-950W	Net weight	4.3kg


PRE-INSTALLATION PRECAUTIONS & INSTALLATION LOCATION

DO NOT install in the following places

- Where the temperature can be below -10°C or above 40°C
- . Where the unit may come into direct contact with excessive water



User Manual



handydryers


INSTALLATION


1 Install metal wall plate


· Fix the metal wall plate to the wall with 5 screws and raw plugs

Live = brown wire, neutral line = blue

 A long power cord is supplied with this machine, trim excess and connect to junction box or spur.







 Using one hand hold the clip open whilst pulling the tray out with other hand



If the power cord is damaged it must be replaced by the manufacturer, its service agent or a qualified person

• A residual current device (RCD) with a rated residual operating current, not exceeding 30mA is recommended

- If power tolerance is above +/- 10% the machine will malfunction
- Please use dedicated spur
- Switch off the power during maintenance
- Excess water tray and filter must be installed
- . In case of malfunction, switch off power immediately
- Ensure power is not connected during installation



Environmental Protection


Do not dispose of electrical waste with household waste, please recycle in appropriate facilities. Check with your Local Authority or retailer for recycling advice.


- If the unit will be in direct or strong sunlight
- If there is a lot of condensation in the environment
- If there are corrosive, neutral or reductive gases present
- 20m or more below, or 2000m or higher than, sea level

Installation position

The following picture shows the recommended position

- Ensure there is at least 150mm clear space below the machine (either to the floor or other objects in the location)
- It is recommended that a minimum distance of100mm should be left clear to either side of the unit
- Avoid locations where people or doors might damage the unit
- Choose a completely flat wall surface to mount the unit to





Replace filter and excess water tray See diagram